



Work Instructions  
**Measuring Width of Leather Laces**  
Date: September 2014

Materials needed:

- 1) Pre Measured Steel Rule – or – Caliper

Pre Measured Steel Rule:

**Step 1)** If using a Pre Measured Steel Rule, which has notches cut out to the correct measurements, place the lace into the first notch so that the pre measured portion is measuring from one cut edge to the next parallel cut edge.



**Step 2.1)** If there is any difficult resistance to putting the lace into the notch, select the notch that is the next size up and repeat steps 1 and 2.

**Step 2.2)** If the lace falls out of the notch immediately, select the notch that is the next size down and repeat steps 1 and 2.

Caliper:

**Step 1)** Set the caliper to a measurement that is visually close to what the lace appears to be.

**Step 2)** Place the lace between the calipers so that they are measuring from one cut edge to the next parallel cut edge.

**Step 3.1)** If there is any difficult resistance to putting the lace into the calipers, set the calipers a little wider and repeat steps 1 through 3.

**Step 3.2)** If the calipers do not hold the lace at all, set them a little closer together and repeat steps 1 through 3.